

URADITI OVE KORAKE 1-3 AKO HOCETE
DA SKENER UVEK BUDE UKLJUCEN

Programming Card

For Handheld CCD / Laser Scanner



Good Read Beeper Selection

(For selective models only)

Tone



High



Medium



Low



Disable

Duration



Long



Medium



Short



Very Short

3
* The default parameter values are framed.
End of Configuration

Copyright © 2009. All rights reserved.
P/N: 593-3000E-006

USB Mode

The USB mode is effectively a keyboard emulator works with hosts that are USB-compatible operating systems and have USB ports. USB compatible operating systems are Windows 98, Windows NT 5.0 and Mac OS 8 and later. No additional software is needed since the USB driver support is built into this operating system.

Keyboard Type



US Keyboard



International Keyboard

Message Terminator



None



Enter



H Tab


Scanning Mode Selection



Trigger Mode



Auto Scan Mode



Alternative Mode



Repeat Mode

2

All program setup must start with reading the "Start of Configuration" label, and read the "End of Configuration" label to save any changes.

Keyboard Wedge Mode

Message Terminator



None



Hor. Tab



Enter



Execute

Keyboard Type Selection



US Keyboard



International Keyboard (ALT Method)



IBM AT

Capital Lock



ON



OFF